

# Assembly Instructions For the Arched Arbor

The item can be found on  
[www.CedarwoodFurniture.com](http://www.CedarwoodFurniture.com)

Call 877-595-8537 to order

**Items:** EY42ARCVD, EY48ARCVD, EY54ARCVD, EY60ARCVD, EY66ARCVD, EY72ARCVD

**Step 1:** Lay the sides of the arbor on a level surface so the screws on the lattice work are facing inward.

**Step 2:** Bolt one of the arches to both of the side pieces.

**Step 3:** Flip over the arbor and bolt the other arch to the sides.

**\*\*\* Be careful not to bind!\*\*\***

**Note:** This will not be sturdy until it is buried in the ground.

**Step 4:** Now set the arbor upright and put the 5 2x4 rafters onto the arches using the 3" screws.

**Step 5:** Measure the bottom of the arbor opening, making sure it is the same as the top opening.

**Step 6.** Now pound a stake at each leg using 2 1/2" screws and fasten to leg.



## Tools Needed for Assembly

Hammer  
Screwdriver  
Tape Measure  
7/16 Socket

## Part List

Side Assembly	(2)
Arches	(2)
2X4 Rafters	(5)
Stakes	(4)

## Hardware

1/4 3" Bolts	(8)
1/4" Nuts	(8)
1/4 x 1" Fender Washers	(16)
3" Screws	(10)
2 1/2" Screws	(8)