



CLUB CHAIR (AQ03)

MATERIALS LIST:

- 1 - Preassembled Seat Section (A)
- 2 - Preassembled Arm & Leg Section (B)
- 1 - Preassembled Back Section (C)
- 8 - 3 1/2" Carriage Bolts, Washers & Nuts

INSTRUCTIONS:

1. Attach the Seat Section (A) to the Arm & Leg Section (B) by inserting a 3 1/2" carriage bolt into the pre-drilled holes. (1A & 2A) Attach washers & nuts and finger tighten. Repeat for the other side.
2. After the Arm & Leg Section (B) is attached to the Seat Section (A), put the Back Section (C) in place so the pre-drilled holes line up with the holes of the Arm & Leg Section (B) and insert carriage bolts into the holes and attach the washers & nuts. (1B & 2B) Repeat for the other side.
You may now tighten all the nuts. It may be necessary to tighten the nuts periodically as the wood dries completely.

NOTE: If and when you are storing your new furniture away for the winter, you should loosen the nuts off slightly. This will allow the wood to expand with the moisture and temperature change. When the weather warms and dries, retighten the nuts.

