



VersaLoft **Assembly Instructions Regular Bed: Twin or Full**

Tools Needed:

Square Drive Bit
Power Screw Driver

Parts List:

2 - Headboards
2 - Side Rails
4 - Legs
1 - Slat Roll
4 - Wooden Caps (Twin Bed)
8 - Wooden Caps (Full Bed)

Hardware List:

 1 - Allen Wrench
 8 - 3 1/2" Bolts
 8 - 2 3/4" Bolts
 30 - 1 1/2" Screws
 8 - Dowel Nuts



Figure 1



Figure 2



Step 1: Attach legs to headboards using 8 - 3 1/2" bolts. Tighten with the Allen Wrench. Fasten ends of headboard caps to top of legs with 4 - 1 1/2" screws in small predrilled holes (See figure 1).

Step 2: Insert dowel nuts into holes on inside of side rails. Attach the headboards to the side rails with 8 - 2 3/4" bolts, turning bolts into dowel nuts with the Allen wrench. (Do not over tighten).

Step 3: Lay the slat roll in the bed frame with the slat string facing up. Attach with the 1 1/2" screws. (See Figure 2). Put wooden caps in holes in headboard caps. Twin bed gets 4 caps - full bed gets 8 caps. These caps are taken out and metal dowels put in if you wish to purchase another bed to use as a bunkbed.

Beds need a standard Twin or Full mattress.