



# PATIO END TABLE

## MATERIALS LIST:

- 1 - Preassembled Table Top Section
- 4 - Legs
- 4 - 3 1/2" Lag Bolts
- 4 - Washers

## INSTRUCTIONS:

1. Position Leg on the outside of the support framework with predrilled hole facing in.
2. Insert 3 1/2" Lag Bolt & Washers through hole of the corner brace and into the Leg. Turn Lag bolt with a wrench until tight. Do not over tighten.
3. Repeat for remaining Legs.

