Assembly Instructions for the Treated Pine Garden Bench

Parts List

Seat (1)

Back (1)

Left Leg Assembly (1) Right Leg Assembly (1)

Hardware

1/4" x 3-1/4" Carriage Bolts (16) 1/4" Flange Nuts (16)

Tools Needed for Assembly

Hammer 7/16" Socket

Step 1 Attach the assembled back and seat together using the 3-1/4" carriage bolts and flange nuts.

Step 2 Attach the arm and leg assembly to the back and seat unit sides using the 3-1/4" carriage bolts and 1/4" flange nuts (be sure the curve faces the outside on the arm when assembly-please view photo).



Cracks may occur with these products. This is a normal and natural occurrence in wood, and will not affect the structural integrity of the wood and this product.