

Assembly Instructions for Treated Pine Rocking Chair

Tools Needed For Assembly:

Pliers or 7/16" Wrench
Hammer
Ratchet and 7/16" Socket

- Step 1:** Lay out all of the parts and identify them by comparing them with the drawings.
- Step 2:** Bolt the back of the rocker to the seat using 4 of the 1/4 x 3-1/4" bolts and nuts.
- Step 3:** Take the leg/arm assembly and attach each to the seat and back of the rocker using 5 bolts per side.
- Step 4:** Take the rocker bottom pieces and attach them to the legs using for 3" carriage bolts.
- Step 5:** Go back over your rocker and tighten all the nuts using a 7/16" socket or pliers.



Cracks may occur with these products. This is a normal and natural occurrence in wood, and will not affect the structural integrity of the wood and this product.