

Swing Bed Assembly Instructions

THE CHARLOTTE



TOOLS NEEDED: DRILL, 5/16" SOCKET OR HEX BIT, PHILIPS HEAD DRILL BIT OR SCREWDRIVER, HAMMER, AND A HELPER

- 1** Attach front face board labeled 1 & 2 to side rails labeled 1 & 2 using provided black bolts

- 2** Attach back panel labeled 3 & 4 to side rails labeled 3 & 4 using short black bolts.

- 3** Attach arms labeled 5 & 6 to back panel labeled 5 & 6 using provided long black bolts.

- 4** Insert mattress support slats evenly across swing and screw into place using gray screws.

- 5** Insert Screw Caps. Use super glue provided and gently tap into place with hammer if needed.
