

Swing Bed Assembly Instructions

THE KIAWAH



TOOLS NEEDED: DRILL, 5/16" SOCKET OR HEX BIT, PHILIPS HEAD DRILL BIT OR SCREWDRIVER, HAMMER, AND A HELPER

- 1** Attach front face board labeled 1 & 2 to side rails labeled 1 & 2 using provided long black bolts. Repeat this for back face board 3 & 4. * Matching numbers

- 2** Attach back panel labeled 5 & 6 to side rails labeled 5 & 6 using provided gray screws (these screws are inside swing attachment holes). Repeat with 7 & 8, and 9 & 10.

- 3** Attach top board labeled 11 & 12 to side rails labeled 11. & 12 using short black bolts.

- 4** Insert mattress support slats. Screw into place using packaged gray screws.

- 5** Insert Screw Caps. Use super glue provided and gently tap into place with hammer if needed.
