

Swing Bed Assembly Instructions

THE SAVANNAH



TOOLS NEEDED: DRILL, 5/16" SOCKET OR HEX BIT, PHILIPS HEAD DRILL BIT OR SCREWDRIVER, HAMMER, AND A HELPER

- 1** Attach front face board labeled 1 & 2 to side rails labeled 1 & 2 using provided black bolts

- 2** Attach back panel labeled 3,4,5, & 6 to side rails labeled 3,4,5, & 6. Attach to side rails using black bolts.

- 3** Insert plugs into all holes showing on the bed. Use super glue and gently tap plugs into place with hammer if needed.

- 4** Insert mattress support slats. Screw into place using gray philip head screws.
