

# Assembly Instructions For The Swingbed

## Tools Needed:

Hammer For Light Tapping  
1/2" Wrench  
Screwgun

## Parts List:

Seat Assembly (1)  
Back Assembly (1)  
Left Arm Assembly (1)  
Right Arm Assembly (1)  
Chains Or Ropes (4)

## Hardware:

1/4" x 4-3/4" Bolts (2)  
1/4" x 2-3/4" Bolts (6)  
1/4" Washers (8)  
5/16" x 3-1/4" Eye Bolts (4)  
5/16" Hex Nuts (4)  
1-3/4" Screws (14)  
Allen Wrench (1)


- Step 1** Fasten the back assembly to the seat assembly. Align the predrilled holes on the bottom of the back assembly with the threaded inserts on the back of the seat & insert two 4-3/4" bolts. Turn into the inserts with the Allen wrench. **NOTE: Do not fully tighten these bolts until Step 2 is completed.**
- Step 2** Fasten the arms to the seat and back. Align the holes on the 2x4's on the bottom of the arm with the threaded inserts in the side of the bed. Put a 2-3/4" bolt through the holes in the 2x4's, turn into the inserts, and tighten with the Allen wrench. Now align the hole in the back of the arm with the threaded insert in the side of the back assembly, put another 2-3/4" bolt through & tighten. (Note: If the holes do not align properly the back assembly can be moved back & forth). Now take the 1-3/4" screws and insert in the predrilled holes in the slats on the arm and fasten to the side of the swingbed with the screwgun. (Extra screws are provided). Now attach the other arm & tighten all bolts.
- Step 3** Put a 1/4" washer on a 3-1/4" eyebolt & put through the hole above the arm on the back assembly. (The eye of the bolt belongs on the outside). Put another 1/4" washer on the inside & put on a 5/16" hex nut and tighten with the 1/2" wrench. Repeat on the other side. Now find the predrilled holes in the side of the seat in front of the arm braces. Repeat above steps & put eyebolts in both holes.

**If your swingbed has chains go to Step 4, if it has ropes skip Step 4 and go to Step 5.**


- Step 4** Attach the chains to the swingbed. The ends without a snap hook attach to hooks at the ceiling. (You will need to get the hooks unless you ordered our swing hanging kit). Attach the snap hooks on two chains to the eyebolts on the back of the swingbed. Take the snap hooks off the other two chains, put the chains through the holes in the swing arms, attach the snap hooks again and fasten to the eyebolts below the arms. The swingbed can be hung from two or four points at the ceiling.
- Step 5** Attach the rope to the swingbed. Take a rope, put the end through the hole in the armrest, & through the eyebolt below the arm. Pull on through the eyebolt & make a knot in the end of the rope. (See photos below). Attach another rope to the eyebolt in the back assembly the same way then repeat on other side. The swingbed is now ready to hang. Hook the rings on hooks at the ceiling or if you purchased comfort springs hook the rings on one end of the springs and hook the other end of the springs to the ceiling. The swingbed can be hung from two points or four points at the ceiling.

- Step 6** You will now need to adjust the ropes until the swingbed is at the desired height. The ropes are all fully adjustable. To lower the swingbed push the bottom loops on the end of the rope further up the rope then hold the top loops with one hand & pull the end of the rope up through the loops. To raise the swingbed pull the rope through the loops in the opposite direction. The ropes attached to the front of the swingbed will need to be adjusted to a different length than the ropes attached to the

How to make a knot:



Step 1



Step 2



Step 3